

SHEETROCK™ Brand Corner Bead

DUR-A-BEAD™

Application

Use drywall nail or staples spaced 9" o.c. in both flanges and placed opposite. Fasten to framing through board. May use "clinch-on" tool to attach. Use correct-size tool for flange width. Finish corner with three coats of joint compound; use only two coats with SHEETROCK® Brand lightweight compounds.

Trademarks

The following trademarks used herein are owned by United States Gypsum Company or a related company: DUR-A-BEAD, SHEETROCK.

Note

Products described here may not be available in all geographic markets. Consult your U.S. Gypsum Company sales office or representative for information.

Notice

We shall not be liable for incidental or consequential damages, directly or indirectly sustained, nor for any loss caused by application of these goods not in accordance with current printed instructions or for other than their intended use. Our liability is expressly limited to replacement of defective goods. Any claim shall be deemed waived unless made in writing to us within thirty (30) days from the date it was or reasonably should have been discovered.

SAFETY FIRST!

Follow good safety practices. Read material safety data sheets and related literature on products before specification and/or installation.

