

FIRECODE® Brand Acrylic Firestop Sealant

Caulk Application

FIRECODE Acrylic Firestop Sealant may be applied using conventional caulking equipment. Apply the firestopping sealant to minimum thickness (per system specifications) on top of safing insulation (where applicable). Ensure that firestopping sealant is in contact with all surfaces and that the entire opening is filled with safing (if required for system applications) and firestopping sealant. The specific system design will specify the necessary amount of forming material and the permitted joint or annular space.

Trademarks

The following trademarks used herein are owned by United States Gypsum Company or a related company: FIRECODE.

Note

Products described here may not be available in all geographic markets. Consult your U.S. Gypsum Company sales office or representative for information.

Notice

We shall not be liable for incidental or consequential damages, directly or indirectly sustained, nor for any loss caused by application of these goods not in accordance with current printed instructions or for other than their intended use. Our liability is expressly limited to replacement of defective goods. Any claim shall be deemed waived unless made in writing to us within thirty (30) days from the date it was or reasonably should have been discovered.

SAFETY FIRST!

Follow good safety practices. Read material safety data sheets and related literature on products before specification and/or installation.

