



USG DUROCK™ BRAND NE FLOOR PATCH

Versatile, trowelable cementitious patching compound

- For interior use over concrete and approved wood subfloors
- Polymer-modified—promotes early strength and workability
- No priming necessary for most applications
- Fast setting—floor coverings may be installed in as little as one hour
- Low energy required to mix and apply
- Featheredge to 1/2 in. (12.7 mm) thick
- May be used as an embossing leveler

DESCRIPTION

USG Durock™ Brand NE Floor Patch is a polymer-modified, cement-based patching compound for interior use over concrete and approved wood subfloors. Ideal for renovation projects, this economical floor patch provides a smooth skim coat for accepting floor coverings. Easy to mix and apply, USG Durock™ NE Floor Patch is fast drying; floor coverings can be installed in as little as one hour.¹ Priming is not required for most applications.² USG Durock™ NE Floor Patch can be mixed with USG Durock™ Brand Matrix Bond Enhancer to maximize bond for high-performance applications or to emboss vinyl floor goods.

1. High humidity, thickness and/or low ambient or substrate temperatures will delay time to floor covering application.
2. Existing gypsum underlayments require special consideration. See Notes/Limitations #7, pg. 3.

VOC EMISSIONS

USG Durock™ Brand NE Floor Patch is defined as a “Low Emitting” material per California Department of Public Health CDPH/EHLB/Standard Method Version 1.1, 2010 (CA Section 01350) for school classroom, single-family residence, and private-office modeling scenarios, and meets USGBC’s LEED® v4 emission requirements.

INSTALLATION SUBFLOOR PREPARATION

All subfloors must be structurally sound, stable and solid. If there is any question about the structural soundness of the subfloor, consult with the engineer on the project or request the services of a professional structural engineer.

Subfloors must be clean and free of dirt, tar, wax, oil, grease, latex compounds, sealers, curing compounds, release agents, asphalt, water-soluble adhesives, paint, chemicals, loose old cementitious products, joint compounds from drywall installation or any other contaminant that might prevent proper bonding of USG Durock™ NE Floor Patch to the host substrate.

Read submittal and SDS before USG Durock™ NE Floor Patch application.

TOOLS

- Mixing bucket
- Trowels
- Razor scraper
- Mixing drill type 2 through 7—as outlined in the *Technical Guidelines*, prepared by the International Concrete Repair Institute, *Pictorial Atlas of Concrete Repair Material Mixing Equipment* (Guideline No. 320.5R-2014)
- Mixing paddle type 2, 3, 4, 8 or 9—as outlined in the *Technical Guidelines*, prepared by the International Concrete Repair Institute, *Pictorial Atlas of Concrete Repair Material Mixing Equipment* (Guideline No. 320.5R-2014)

MIXING RATIO

Five parts USG Durock™ NE Floor Patch to 1.5 parts water by weight, or 3.5–4.0 quarts (3.3–3.8 L) of water per one (1) 25 lb. bag (11.3 kg) of USG Durock™ NE Floor Patch.

MIXING (CONT.)
INSTRUCTIONS

To mix a 25 lb. (11.3 kg) bag of USG Durock™ NE Floor Patch, first add 3.5–4.0 quarts (3.3–3.8 L) of clean water to a mixing bucket, then add the floor patch. Mix with a paddle and drill. To mix smaller quantities by hand, use five parts USG Durock™ NE Floor Patch to 1.5 parts water by weight. Mix for a maximum of two minutes with a trowel to achieve a smooth, lump-free consistency. Do not overwater.

Use USG Durock™ NE Floor Patch within 10–20 minutes after mixing. Remix (without adding water) as needed within this time frame. Dispose of any USG Durock™ NE Floor Patch once setting has occurred.

APPLICATION

During application and until USG Durock™ NE Floor Patch is set (typically within 60–90 minutes, depending on floor patch thickness and drying conditions), close all doors, windows and other openings in the building and turn off HVAC systems to prevent air drafts. Protect installation areas from direct sunlight exposure during setting time. Thereafter, the HVAC system can resume, as well as the use of doors, windows and other openings.

The subfloor, room temperature and USG Durock™ NE Floor Patch product—either mixed or in powdered form—must be between 50 °F and 95 °F (10–35 °C) at the time of application and for 72 hours after installation of USG Durock™ NE Floor Patch. For temperatures above 95 °F (35 °C), consult USG.

It is recommended to patch several small test areas before conducting full installation of USG Durock™ NE Floor Patch. The test areas must also include finish flooring to establish suitability of the complete system for intended use.

USG Durock™ NE Floor Patch has a working time of approximately 10–20 minutes at 70 °F (21 °C)/50% RH (at higher temperatures the working time is shortened; at lower temperatures the working time is extended).

CONCRETE SUBFLOORS

Concrete subfloors receiving cementitious floor patch must be cured properly (generally for a minimum of 28 days) prior to floor patch installation. Subfloor moisture vapor emission rate (MVER) exceeding 5 lbs.(2.3 kg)/1000 sq. ft.(92.9 m²)/24 hours per ASTM F1869-16 must be treated with USG Durock™ Brand RH-100™ Moisture Vapor Reducer. If moisture mitigation is required, the surface of the USG Durock™ Brand RH-100 Moisture Vapor Reducer must be primed with USG Durock™ Brand Primer-Sealer prior to application of USG Durock™ Brand NE Floor Patch. USG Durock™ NE Floor Patch is not a vapor barrier. Transmission of excessive moisture vapors from the concrete subfloor through USG Durock™ NE Floor Patch can interfere with floor-covering adhesives and compromise their performance.

A weak or degraded concrete surface layer must be removed mechanically to provide a solid base. To decide whether mechanical preparation of substrate is required or not, the concrete substrate must be thoroughly assessed for its quality and tensile strength over the entire application area. The assessment of concrete tensile strength must be made in its existing state without the removal of any foreign material that may be present on the concrete surface. Simple visual appearance of concrete substrate as strong and solid does not necessarily guarantee that the concrete substrate is free of impurities and has the right tensile strength.

Concrete exhibiting signs of laitance (a layer of weak material on the concrete surface either visible or invisible), scaling, spalling, crumbling or delamination must be mechanically removed to achieve a solid and clean substrate. Use mechanical removal methods such as shot blasting, scarifying or diamond grinding to clean and prepare the concrete subfloor contaminated with adhesives, asphalt or oil. Shot blasting is the preferred method of mechanically profiling and preparing the concrete subfloor for the application of USG Durock™ NE Floor Patch.

If cracks are found in the existing concrete subfloor, they must be inspected by the engineer on the project or a professional structural engineer to determine if the crack is due to typical concrete “shrink” or if it is a result of a structural movement. In the case of the latter, remediation of the crack must be addressed or eventually the crack will telegraph through USG Durock™ NE Floor Patch. Repair all existing cracks in old and new concrete to minimize and control their ability to telegraph through the layer of USG Durock™ NE Floor Patch. Remove the weak concrete along the length of the cracks by chiseling or other suitable means. Remove accumulated dust and debris from the crack cavities using a vacuum or other suitable means. Various cracks present in the concrete subfloor, including shrinkage cracks, must be filled with a suitable commercially available crack-fill epoxy adhesive designed for concrete flooring applications. To ensure superior resistance to crack growth, use injection epoxy crack-repair techniques per manufacturer guidelines to repair cracks that are active or deep.

CONCRETE SUBFLOORS CONT.

Note that repair of existing cracks in the concrete subfloor only subdues but does not completely prevent their ability to telegraph through USG Durock™ NE Floor Patch. Growth of existing cracks or formation of new cracks in the concrete subfloor can lead to cracks telegraphing through USG Durock™ NE Floor Patch. Respect existing expansion and control joints (see Notes/Limitations #9, pg. 3).

Priming is not required over concrete. USG Durock™ NE Floor Patch may be applied from featheredge to 1/2 in. (12.7 mm) thick over concrete subfloors.

GYPSUM UNDERLAYMENTS

USG Durock™ NE Floor Patch can be used over gypsum underlayments. Existing gypsum underlayments must be solid with no cracks and be dust free. Underlayment must be sealed with USG Durock™ Brand Primer-Sealer or USG Durock™ Brand X2 Primer-Sealer. First test surface hardness by scratching existing underlayment with a coin. If surface can be gouged, do not use USG Durock™ NE Floor Patch and consult USG for alternative repair methods.

WOOD SUBFLOORS

USG Durock™ NE Floor Patch can be applied over engineer-approved, APA-Rated exterior glue plywood or oriented strand board (OSB) (i.e., APA-Rated Exterior or Exposure 1 panels) wood subfloors.

Before application, subfloor must be properly prepared (see Notes/Limitations #20, pg. 4 for subfloor deflections) and loose boards secured with deck screws. Priming is not required over wood subfloors. USG Durock™ NE Floor Patch may be applied from featheredge to 1/2 in. (12.7 mm) thick over approved wood subfloors.

FLOOR-COVERING INSTALLATION

USG Durock™ NE Floor Patch may be ready for floor covering in as little as 60 minutes after application (at 70 °F (21 °C)). Drying time is dependent on job site temperature and humidity conditions as well as application thickness. For example, high humidity and/or low substrate temperatures will extend dry times.

- Floor coverings such as ceramic tile, VCT, sheet vinyl and carpeting can be installed as soon as USG Durock™ NE Floor Patch can be worked on without damaging the surface.
 - Nonbreathable floor coverings requiring special adhesives that are sensitive to moisture; high-performance adhesives such as urethanes or epoxies; and wood flooring can be installed after 16 hours.
 - Check with floor-covering and adhesive manufacturers for installation guidelines and suitability of their manufactured products over USG Durock™ NE Floor Patch.
 - Protect the surface of USG Durock™ NE Floor Patch from contaminants and water until installation of floor covering is accomplished.
 - Perform field bond test to determine adhesive/flooring performance over USG Durock™ NE Floor Patch. Install floor covering with adhesive and perform field bond test approximately 72 hours after installation.
 - Follow floor-covering manufacturers' recommendations for surface-sealing requirements. If the floor-covering or adhesive manufacturer requirements are more stringent, their requirements take precedence.
-

NOTES/LIMITATIONS

1. Do not use in exterior applications.
2. Do not use as a wear surface.
3. Do not install where continuous exposure to moisture is a possibility.
4. Do not install over dimensionally unstable, improperly prepared, weak subfloors.
5. Do not install over concrete subfloor less than 28 days old. For untreated (without an approved moisture mitigation system) concrete subfloors less than 28 days old, contact USG.
6. For below-grade applications, contact USG.
7. Existing gypsum underlayments must be solid with no cracks and dust free. Gypsum underlayment must be sealed with USG Durock™ Primer-Sealer or X2 Primer-Sealer. First test surface hardness by scratching existing underlayment with a coin. If surface can be gouged, do not use USG Durock™ NE Floor Patch and consult USG for alternative repair methods.
8. Do not apply directly to sound mat.

NOTES/LIMITATIONS CONT.

9. Do not use over expansion or isolation joints. Continue all movement joints in the concrete slab up through the layer of underlayment. In areas where the expansion or isolation joints are not present in the floor or where the concrete slab has developed systematic cracks in response to slab movement, consult with an engineer on the project or request the services of a professional structural engineer to provide such joints as part of the system in accordance with engineering requirements and industry standards.
10. Existing cracks in the new and old concrete must be repaired with an appropriate crack repair material in accordance with industry recommendations prior to installation of USG Durock™ NE Floor Patch. Note that repair of existing cracks in the concrete subfloor only subdues but does not completely prevent their ability to telegraph through USG Durock™ NE Floor Patch. Growth of existing cracks or formation of new cracks in the concrete subfloor can lead to cracks telegraphing through the floor patch.
11. When the MVER exceeds 5 lbs.(2.3 kg)/1000 sq. ft.(92.9 m²)/24 hours, treat the concrete subfloor with USG Durock™ Brand RH-100™ Moisture Vapor Reducer in all areas of use where potential for moisture problems may exist. USG Durock™ NE Floor Patch is not a vapor or moisture barrier. Transmission of excessive water vapors or moisture from the concrete subfloor through the USG Durock™ NE Floor Patch can interfere with floor-covering adhesives and compromise their performance.
12. For on-grade applications, use USG Durock™ RH-100 Moisture Vapor Reducer over concrete. Moisture mitigation system may not be needed if a vapor retarder is installed below the concrete slab in accordance to industry specifications and practice (ASTM E1745, ASTM E1993, ASTM E1693) and the MVER value of the concrete slab is below 5 lbs.(2.3 kg)/1000 sq. ft. (92.9 m²)/24 hours.
13. Do not use acid etching as a method of cleaning and preparing the concrete subfloor.
14. Do not use oil-based sweeping compounds to clean and prepare the concrete subfloor. Use of such sweeping compounds leaves an oil film on the surface of the concrete that will interfere with the USG Durock™ NE Floor Patch's bond development. Use vacuum or a dry broom to remove the dust and debris and prepare the subfloor for USG Durock™ NE Floor Patch application.
15. Do not use adhesive-removing chemicals or solvents to eliminate contaminants from the concrete subfloor. Use of such chemicals can transport oil, grease and other contaminants further into the concrete pores. These chemicals can be released back to the surface at a later time to interfere with the floor-covering adhesives, thus compromising the bond performance with USG Durock™ NE Floor Patch. Mechanically removing the organic adhesives, asphalt, coal-tar-based adhesives and other oil-based contaminants is the sole recommended method of preparing the subfloor for application of USG Durock™ NE Floor Patch.
16. For application over materials containing asbestos, contact USG. Do not mechanically remove organic adhesives, asphalt, coal-tar-based adhesives or other materials containing asbestos—contact an asbestos abatement professional.
17. Do not overwater or overmix.
18. Do not add non-USG approved chemical additives or polymers to USG Durock™ NE Floor Patch.
19. Existing curing compounds on concrete surfaces must be removed. Shot blasting is the only recommended method of removal.
20. Do not mix with other cementitious products or self-leveling materials.
21. Structure shall be designed so deflection does not exceed L/240 from combined dead and live loads and L/360 from live loads. Certain floor coverings such as marble, limestone, travertine and wood may have more restrictive deflection limits. Consult the appropriate floor-covering manufacturer.

PRODUCT DATA

Mixing Ratio: 25 lb. bag USG Durock™ NE Floor Patch to 3.5–4.0 quarts (3.3–3.8 L) of water (5 parts USG Durock™ NE Floor Patch to 1.5 parts water by weight)

Approximate Coverage:

Up to 78 sq. ft. (7.2 m²)/bag at 1/16 in. (1.6 mm) thickness

Up to 39 sq. ft. (3.6 m²)/bag at 1/8 in. (3 mm) thickness

Up to 19.5 sq. ft. (1.8 m²)/bag at 1/4 in. (6.4 mm) thickness

Approximate Working Time: 10–20 minutes at 70 °F (21 °C)/50% RH

Application of Floor Covering: In as little as 60 minutes or when USG Durock™ NE Floor Patch can be worked on without damaging the surface. Drying time is dependent on job site temperature and humidity conditions as well as application thickness.

Thickness Range: Featheredge to 1/2 in. (12.7 mm) thick

Packaging: 25 lb. (11.3 kg) multiwall paper bags

Note: Physical characteristics published herein were achieved under controlled laboratory conditions. Actual field results may differ due to environmental conditions, inconsistent proportioning of field-applied water and USG Durock™ NE Floor Patch, as well as differences in mixing equipment.

STORAGE

USG Durock™ NE Floor Patch should be stored in an enclosed shelter providing protection from damage and exposure from the elements. During winter, dry mix material should be stored in a heated room before application, as deeply cooled material may increase the risk that some additives may not dissolve during mixing. If temperature is too high, premature setting may occur. Protect unused material by removing air from bag and sealing tightly. Remove damaged or deteriorated materials from the job site. USG Durock™ NE Floor Patch has a shelf life of 12 months from the manufactured date.

CLEANUP

Clean tools with water immediately after use and before USG Durock™ NE Floor Patch dries.

SUBMITTAL APPROVALS

Job Name	
Contractor	Date

PRODUCT INFORMATION

See usg.com for the most up-to-date product information.

DANGER

Causes skin irritation. Causes serious eye damage. May cause an allergic skin reaction. May cause respiratory irritation. May cause cancer by inhalation of respirable crystalline silica. Do not handle until all safety precautions have been read and understood. Avoid breathing dust. Use only in a well-ventilated area; wear a NIOSH/MSHA-approved respirator. Wear protective gloves/protective clothing/eye protection. If swallowed, inhaled, or skin irritation occurs get medical attention. If on skin: Wash with plenty of water. If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses and continue rinsing. Contaminated work clothing should not be allowed out of the workplace. Wash contaminated clothing before reuse. When mixed with water, this material hardens and becomes very hot sometimes quickly. DO NOT attempt to make a cast enclosing any part of the body using this material. Dispose of in accordance with local, state, and federal regulations. For more information call Product Safety: 800 507-8899 or see the SDS at usg.com
KEEP OUT OF REACH OF CHILDREN.

TRADEMARKS

The trademarks USG, DUROCK, MATRIX, RH-100, IT'S YOUR WORLD. BUILD IT., the USG logo, the design elements and colors, and related marks are trademarks of USG Corporation or its affiliates.

LEED is a registered trademark of the U.S. Green Building Council

NOTE

The information in this document is subject to change without notice. USG Corp. assumes no responsibility for any errors that may inadvertently appear in this document. Consult your USG Company sales office or representative for information.

NOTICE

We shall not be liable for incidental or consequential damages, directly or indirectly sustained, nor for any loss caused by application of these goods not in accordance with current printed instruction or for other than the intended use. Our liability is expressly limited to replacement of defective goods. Any claim shall be deemed waived unless made in writing to us within thirty (30) days from date it was or reasonably should have been discovered.

SAFETY FIRST!

Follow good safety/industrial hygiene practices during installation. Wear appropriate personal protective equipment. Read SDS and literature before specification and installation.

800 USG.4YOU
800 (874-4968)
usg.com

Manufactured by or for
United States Gypsum Company
550 West Adams Street
Chicago, IL 60661

CB674-USA-ENG/rev. 11-16
© 2016 USG Corporation and/or
its affiliates. All rights reserved.
Printed in U.S.A.

USG
IT'S YOUR WORLD. BUILD IT.®